

	
<p>1. Be sure to store your glasses in a hard case when you are not wearing them to ensure that you do not lose them or accidentally drop your frame. Always use both hands to put the glasses on and off.</p>	<p>1. Do not wear your frame on your head. This will eventually overstretch the temples and the front of the frame over time and will change the fit of the frame. In general, do not try to adjust your glasses frame yourself, to bring it back into shape. To do this, go to an optician.</p>
<p>2. Rinse your glasses frequently with warm water. Use a mild washing-up liquid for cleaning, then rinse the glasses frame with clear water and then dry the glasses with a clean cleaning cloth. You should also use an ultrasonic cleaning at least every 4-6 months (max. 4 minutes per process) to better clean e.g. hinges and nose pads. Also take into account the instructions for use included with the ultrasound device.</p>	<p>2. Avoid wearing your frame while spraying hairspray or sunscreen on your face.</p> <p>Remove sweat and grease residues to prevent biological and chemical exposure. Do not use any aggressive cleaning agents such as window cleaners or cleaning cloths containing alcohol. Do not wear the glasses during/ directly after hair coloring, as color residue may occur.</p>
<p>3. Check your glasses periodically to make sure the screws are not loose – if you find one, gently tighten it with a small screwdriver or stop by your optometrist. Have your glasses checked by an optician at least once a year to ensure that they are correctly fitted.</p>	<p>3. Do not expose your glasses frames to intense sunlight and very high temperatures for too long. Don't leave your eyeglass frames behind the windshield of your car. Acetate is very sensitive to heat and may deform. Direct sunlight causes the frame to age faster.</p>